



ZIPPEESHADE™

THE ORIGINAL SUNROOF SHADE



HOW TO INSTALL YOUR ZIPPEESHADE

In order for you ZippeeShade to fit properly you must follow these instructions



Step 1:

Once you have removed your ZippeeShade from its carrying case, you may notice that the UV Resistant fabric is wrinkled.



Step 2:

We recommend that you take a standard steam iron, and set it to the lowest setting yet allowing the steam to work. First iron the ZippeeShade on the silver side, so that you will not damage the printed logo. Once you have smoothed out all the wrinkles, you can turn the ZippeeShade over, and begin ironing the black side.



Step 3:

Be sure to iron the loose fabric that surrounds the frame.



Step 4:

To install the ZippeeShade, slide back the mesh screen covering your sunroof, and slide the ZippeeShade between the glass and mesh screen.



Step 5:

Take the suction cups and depress them against the glass above.

Step 6:

Take the loose fabric and tuck it into the edges of sunroof trim ring. It's that easy.

PLEASE READ:

To prevent damage or loss of your ZippeeShade, we highly recommend that you remove the ZippeeShade from your Front Sunroof before you open it.